



Somfy Controller Programming


7301 - Eolis 3D Wirefree Wind Sensor (Jiggly Wiggly)



Step 1

Remove sensor housing & install 2 AAA batteries
Make sure **down** button on remote is taking unit **out**

1 Step 2 Press the programming button #1 then #2 and release each when the unit jogs



2 - Factory default

Sensitivity

1 - Most sensitive ~ 9 - Least sensitive

Final Step

Test the sensor


Instruct customer on use of products and replacing batteries

7302 - Sunis Wirefree Sun Sensor

Light sensing eye



Front View



Back View

Step 1



Place Sunis (solar powered sun sensor) in a sunny area to charge for 10 min

Step 2



Completely retract the unit. Press the **Programming Button** (with a pen) on the back of the remote and release when the unit jogs

Step 3



Press the **Programming Button** (with a pen) on the back of the Sunis and release when the unit jogs